


DS 2800 S Brushcutter - Engine




DS 2800 S Brushcutter - Engine



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50060012	Air purge				
2	1	61280102R	Cylinder cover				BT3-090-03/10
3	1	4191069B	Plate		matr.2220420945		BT3-102-01/11
4	2	3806014	Screw		17/10/2010		
5	1	61070055	Plate		17/10/2010		
6	1	3035040R	Bearing				
7	1	61280010BR	Muffler				BT3-086-10/09
8	1	61280008CR	Gasket				BT3-086-10/09
9	1	3055120	Spark plug				
10	1	61280005R	Gasket				
11	1	61290003R	Piston ring				
12	2	093000167	Ring				
13	1	072700045R	Piston pin				
14	1	61292031	Piston assy Ø34				
15	1	61292032	Cylinder assembly				
16	1	072700046R	Bearing				
17	2	074000267AR	Washer				
18	1	61280009R	Gasket				
19	1	61280100R	Stopper				BT3-090-03/10
20	1	3028013R	Key				
21	1	3860096	Screw				
22	1	61280043AR	Crankcase				BT3-086-10/09
23	1	3050038R	Seal ring				
24	1	3050037R	Seal ring				
25	4	3860095R	Screw				
26	1	61280004R	Crankshaft				
27	3	61280044R	Plug				
28	1	61250249R	Adjust. pin				BT3-090-03/10

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
29	2	3960030	Screw			matr.2220420945	BT3- 102- 01/11
30	1	3960087AR	Screw				BT3- 090- 03/10
31	1	61282025	Gasket set				
32	1	61292033R	Short block				
34	2	4175162A	Screw	18/10/2010			
35	1	4175089A	Screw	matr. 2229380435			BT3086- 10/09

DS 2800 S Brushcutter - Starter Assy and clutch






DS 2800 S Brushcutter - Starter assy and clutch



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61280023AR	Ignition coil				
2	4	61052008R	Screw				
3	2	61170014	Spacer				
4	1	61280123R	Cable	matr.2220420946			BT3-102-01/11
4	1	61170017R	Cable		matr.2220420945		BT3-102-01/11
5	2	3916004	Washer				
6	2	3819005	Washer				
7	2	006000085	Screw				
8	4	3801013R	Screw				
9	1	3980012	Nut		matr.2221019999		BT3-103-01/11
10	1	61280025R	Flywheel		matr.2221019999		BT3-103-01/11
11	1	56560034R	Clutch driver				
12	1	3960070AR	Screw				
13	1	094600054	Washer				
14	1	61172004R	Compl. pulley				
15	1	61070091R	Clutch		matr.2221019999		BT3-103-01/11
16	1	61070019AR	Starter rope				
17	1	56530018R	Handle				
18	1	56530021	Washer				
19	1	56530019	Spring				
20	1	56530020	Insert				
21	1	61170054	Starter assy				
22	1	3035023R	Hook				
23	1	3025019	Ring				
24	1	61292021	Starter case				
25	1	3024012	Ring				
26	1	61170086	Bushing				
27	2	3801016	Screw				
28	1	61170085	Upper adaptor				
29	1	61170084	Lower adaptor				
30	2	3914003	Nut				
31	1	4161428	Shock absorber				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
32	1	61070022CR	Clutch drum		matr.2221019999		BT3-103-01/11
33	1	61170137B	Bolt kit		matr.2221019999		BT3-103-01/11
34	1	61070090R	Spring		matr.2221019999		BT3-103-01/11
35	1	61070036R	Spring				
36	1	61170173R	Washer				
37	1	3912009	Nut	matr.2221020001			BT3-103-01/11
38	1	3833080	Washer	matr.2221020001			BT3-103-01/11
39	1	3916009	Washer	matr.2221020001			BT3-103-01/11
40	1	61280109R	Flywheel	matr.2221020001			BT3-103-01/11
41	1	61280151	Set (Spacer)	matr.2221201101			BT3-107-06/11
42	2	4138494	Spring	matr.2221020001			BT3-103-01/11
43	1	61280135AR	Clutch assy	matr.2221201101			BT3-103-01/11; BT3-107-06/11
44	4	3918007	Washer	matr.2221020001			BT3-103-01/11; BT3-107-06/11
45	2	3806040	Screw	matr.2221020001			BT3-103-01/11
46	1	61280130R	Clutch drum	matr.2221020001			BT3-103-01/11

DS 2800 S Brushcutter - Fuel tank and air filter




DS 2800 S Brushcutter - Fuel tank and air filter



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	072700077AR	Gasket				
2	1	2318705BR	Carburetor WT-930B				
3	1	61280029	Support				
4	2	3833073	Washer				
5	2	4175163	Screw				
6	1	61170052A	Guard				
7	1	61170016R	Air filter				
8	1	61170040AR	Air filter cover				
9	1	61280055	Tube				
10	1	61070011A	Breather valve				
11	1	4098377	Band				
12	1	4161211	Bush				
13	1	61070079R	Tank cap				
14	1	61070006	Gasket				
15	1	61280056	Tube				
16	1	094600450R	Fuel filter				
17	1	61282030R	Complete tank				
18	1	61170041	Stand				
19	3	3918005	Washer				
20	3	3819006	Washer				
21	3	3801013R	Screw				
22	1	61280059R	Gasket				
23	1	074000130C	Insulator				
24	1	61290004R	Spacer				
25	2	3960069AR	Screw				
26	1	072700076A	Gasket				
27	1	61282025B	Gasket set				
28	1	61110162	Bushing				
29	1	61070078	Tube				

DS 2800 S Brushcutter - Transmission



DS 2800 S Brushcutter - Transmission



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61040052	Pawl				
2	1	61040057R	Spring				
3	1	61040056R	Spring				
4	1	61040049	Throttle lever				
5	1	61170080	Band				
6	1	3960061AR	Screw				
7	1	61040054	Plate				
8	2	3914003	Nut				
9	1	61290010R	Bevel gear Ø24		matr.2221019999		BT3- 103- 01/11
10	1	3801011	Screw				
11	3	3960067AR	Screw				
12	1	61040050A	Lever				
13	1	61040053	Plate				
14	1	61070042	Switch				
15	1	61072049	Handle				
16	1	61280061AR	Throttle cable				BT3- 090- 03/10
17	1	61280122R	Cable	matr.2220420946			BT3- 102- 01/11
17	1	61280060AR	Cable		matr.2220420945		BT3- 090- 03/10; BT3- 102- 01/11
18	5	3801015	Screw				
19	4	3819006	Washer				
20	4	3916005	Washer				
21	1	61170088	Clamp				
22	1	61170103A	Handle				
23	4	61170133	Insert				
24	1	61170175R	Band d.24				
25	1	61290011R	Tube Ø24				
26	1	61280066R	Drive shaft				BT3- 103- 01/11
27	1	3901008	Screw				
28	1	3901016	Screw				


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
29	1	61170119AR	Gear case				
30	1	3035043	Bearing				
31	1	3035044	Bearing				
32	1	3025026	Ring				
33	1	3024009R	Ring				
34	1	3906030	Screw				
35	1	3035045	Bearing				
36	1	61170122	Shaft				
37	1	3034008	Bearing				
38	1	3025018	Ring				
39	1	61170134	Seal ring				
40	1	61170123	Hub				
41	1	61170124	Thrust washer				
42	1	3933105	Nut				
43	1	61282028	Bevel gear		matr.2221019999		BT3-103-01/11
44	1	4162154B	Hand grip				
45	1	61280065R	Joint		matr.2221019999		BT3-103-01/11
46	1	61280064R	Shaft		matr.2221019999		BT3-103-01/11
47	1	61110074R	Guard				
48	1	61250274R	Flexible shaft	matr.2221020001			BT3-103-01/11
49	1	61280129AR	Torsion damper	matr.2221020001			BT3-103-01/11
50	1	61170066BR	Bevel gear d.26	matr.2221020001			BT3-103-01/11
51	1	61170135	Bevel gear set	matr.2221020001			BT3-103-01/11

DS 2800 S Brushcutter - Carburetor



Walbro mod. WT-930

compl. p.n. 2318705



15 ■ KIT RIPARAZIONE
REPAIR KIT





16 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET

DS 2800 S Brushcutter - Carburetor



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	074000240	Adjust.screw				
2	1	095000164	Ring				
3	1	375100078	Shutter				
4	1	2318211	Pin				
5	1	2318737	Shaft				
6	1	072700347	Spring				
7	1	2318631	Adjust. screw				
8	2	2318867	Cap				
9	1	094600148	Spring				
10	1	2318191	Cover				
11	4	035000162	Screw				
12	1	003300202	Screw				
13	1	50050107	Cover				
14	1	003300201	Spindle				
15	1	094600209	Repair kit				
16	1	094600210	Kit guarn				

DS 2800 S Brushcutter - Accessories



DS 2800 S Brushcutter - Accessories



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61172019A	Tap'n go head with 2 nylon lines				
2	2	3960040R	Screw				
3	1	61240161R	Plate				
4	4	3801010R	Screw				
5	1	4179113A	Skirt w/blade				
6	1	4174275R	Blade				
7	1	61072044	Plastic guard				
8	2	4199005A	Bushing				
9	1	61110076	Insert				
10	1	4199004	Spring				
11	1	4199014A	Nylon spool Ø2.4				
12	1	4199046	Cover				
13	1	4095673AR	Disk 3t				
14	1	61260029	Tool kit				
15	1	4160463AR	Single harness				
16	1	61292027	Labels kit				
17	4	3819006	Washer				