





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	3055118	Spark plug				
2	4	005100906AR	Screw				
3	4	3833076	Washer				
4	1	50010215	Decompressor				
5	2	097000055R	Piston ring Ø52				
6	1	094500007R	Piston pin				
7	2	007201198	Ring				
8	1	097000205B	Piston assy.d.50				
9	1	097000206C	Cylinder kit & pi				
10	1	52010458R	Gasket				
11	1	50200124R	Grommet				
12	1	50012008R	Fuel cap				
13	1	026400017	Bearing				
14	1	097000001R	Crankshaft				
15	1	094500028R	Key				
16	1	097000009AR	Gasket				
17	1	094500004R	Seal ring				
18	1	50192025R	Crankcase				
19	2	099900006	Bearing				
20	1	50202039	Throttle rod kit				
21	1	50200089R	Cable				
22	1	098000076	Clamp				
23	1	099900368B	Chain tensioner				
24	2	3023008R	Pin				
25	1	097000229R	Breather valve				
26	2	097000262	Bar stud 9mm				
27	1	097000283	Plate				
28	1	3833073	Washer				
29	1	006000251R	Screw				
30	4	005100988BR	Screw				
31	1	093000478AR	Screws				
32	1	3801010R	Screw				
33	1	099900090	O-ring				
34	1	52010134R	Plate				
35	1	099900014R	Seal ring				





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	094600097A	Spark plug cap				
2	1	094600169A	Spring				
3	1	50200088R	Cable				
4	1	50190036R	Ignition coil				
5	2	3916004	Washer				
6	2	006000315	Washer				
7	2	094000227	Screw				
8	2	52012027	Pawl kit				
9	1	52010326BR	Flywheel				
10	1	005000361	Washer				
11	1	3833080	Washer				
12	1	004000142	Nut				
13	1	52012118BR	Compl spring				
14	1	52010485BR	Pulley				
15	1	3918006	Washer				
16	1	3908036	Screw				
17	4	3960017AR	Screw				
18	1	50140056	Cap				
19	1	097000037R	Starter rope				
20	1	097000064A	Handle				
21	4	3860095R	Screw				
22	1	50200123R	Flange				
23	1	52010180	Cover				
24	1	50200069R	Starter assy				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50200007R	Knob				
2	1	50200036R	Cover				
3	1	50200009AR	Air filter 60 micron (standard)				BT4-099-08/09
3	1	50200122R	Air filter 40 micron (optional)				
4	1	50200010AR	Gasket				BT4-099-08/09
5	1	50200013R	Deflector				
6	1	50190026AR	Cover				
7	1	50200068R	Fuel tank				
8	1	50200030R	Guard				
9	1	50010218R	Fuel filter				
10	1	50200063R	Cover				
11	1	50200017R	Handle				
12	4	097000061A	Screw				
13	1	50200024R	Throttle spring				
14	1	50012008R	Fuel cap				
15	1	099900090	O-ring				
16	1	099900083A	Tank breather				
17	3	3960040R	Screw				
18	1	50010157	Throttle				
19	1	097000028R	Spring				
20	1	50200040R	Trigger interlock				
21	4	097000038AR	Shock absorber				
22	1	50200113R	Cap				
23	1	098000319	Tube				
24	2	50200023R	Support				
25	2	3960099R	Screw				
26	1	50070126R	Spacer				
27	1	50010150R	Plate				
28	1	094600041AR	Screw				
29	3	3860096	Screw				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	3801052R	Screw				
2	3	3033074	Washer				
3	1	097000342A	Cover				
4	2	3860095R	Screw				
5	2	3916005	Washer				
6	1	3960057R	Screw				
7	2	3833073	Washer				
8	2	3801067	Screw				
9	1	097000440A	Muffler				
10	1	097000094CR	Gasket				
11	1	097000043	Manifold				
12	1	50200016R	Gasket				
13	1	50202040R	Compl.support				
14	2	50200117R	Support				
15	2	50200034R	Support				
16	1	50200038R	Gasket				
17	1	50200015AR	Clamp				
18	2	50030272	Screw				
19	1	3057005	Washer				
20	1	50200031R	Spring				
21	1	50200026R	Lever				
22	1	2318795R	Carburetor WJ-121				
23	1	50200033AR	Support				
24	1	52010370A	Grommet				
25	1	50010197	Screen				
26	1	50010198	Deflector				
27	2	3833073	Washer				
28	2	005100913B	Screw				
29	1	50010199	Muffler guard				
30	2	097000092AR	Screw				
31	1	094600126	Tube				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	097000276	Guard				
2	2	50070149	Guard				
3	1	097000277	Plate				
4	2	61052009B	Screw				
5	1	097000147A	Oil filter				
6	2	097000070	Washer				
7	1	097000071A	Spring				
8	1	097000067	Screw				
9	1	097000069B	Piston pump				
10	1	097000078	Cap				
11	1	097000068	Clamp				
12	1	097000062	Pin				
13	1	097000359	Tube				
14	1	097000131B	Oil pump				
15	3	005100905	Screw				
16	1	097000073	Washer				
17	1	097000072	Worm gear				
18	1	097000011	Bearing				
19	1	006100730	Ring 3/8"				
20	1	097000207	Clutch drum				
21	1	097000097	Washer				
22	1	097000132R	Clutch				
23	1	097000098	Spring				
24	2	3960045	Screw				
25	1	097000275	Plate				
26	1	50202011R	Chain cover assy				
27	1	3026003	Ring				
28	1	097000146	Lever				
29	1	099900152A	Spring				
30	1	006000300	Bushing				
31	1	097000107	Pin				
32	1	50010088AR	Spring				
33	1	50200028R	Baffle pl.black				
34	1	097000105	Brake band				
35	1	50010084	Plate				
36	2	50010148R	Nut				
37	1	50200042R	Guard				
38	1	097000106	Pin				
39	2	097000109A	Spike				
40	1	006000156	Screw				
41	2	3914003	Nut				
42	2	006000251R	Screw				

Walbro WJ-121
compl. p.n. 2318795



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	5	035000162	Screw				
2	1	097000156	Cover				
3	1	097000221	Diaphragm and gasket set				
4	1	097000220	Repair kit				
5	1	2318797	Shaft				
6	1	50050109	Bushing				
7	1	2318798	Lever				
8	1	2318796	Spring				
9	4	035000161	Screw				
10	1	2318799	Lever				
11	1	035000149	Plate				
12	1	003300202	Screw				
13	1	035000169	Fulcrum pin				
14	2	50010141	Screw				
15	1	035000151	Shutter				
16	1	095000164	Ring				
17	1	2318804	Screw "H				
18	2	2318867	Cap				
19	1	2318634	Cap				
20	1	097000162	Screw				
21	1	2318763	Spring				
22	1	097000161	Spring				
23	2	097000224	Bushing				
24	1	52010019	Shutter				
25	1	097000154	Shaft				
26	1	097000157	Cover				
27	1	50192023	Decals set				
28	1	094600120A	Tool kit				